

Goodrive28 Series VFD Quick Start Guide


This guide briefly describes the external wiring, terminals, Scan the QR code to view keypads, quick running, common function parameter the full version of GD28 settings, common faults and solutions, product dimensions, series product e-manual, and energy efficiency data of Goodrive28 (GD28 for short) series variable-frequency drive (VFD).

Visit www.invt.com for more information and source download. For details, see the full version of corresponding product e-manual.




- Warning**
- This guide only provides the basic installation and commissioning information. Failure to comply with the safety instructions and installation and commissioning instructions in the relevant documentation may result in accidents such as equipment damage, personal injury, or even death.
 - Only trained and qualified professionals are allowed to carry out related operations.
- Danger**
- Do not perform any operations including wiring, inspection, or component replacement when power supply is applied. Before performing these operations, ensure all the input power supplies have been disconnected, and wait for at least the time designated on the VFD.
- | Minimum waiting time | VFD model |
|----------------------|--|
| 5 minutes | 1PH 220V 0.2–4kW; 3PH 220V 0.2–15kW; 3PH 380V 0.4–22kW |

1 External wiring



2 Electrical wiring

Figure 2-1 Typical VFD wiring




3 Function

Table 3-1 VFD terminal description

Terminal symbol	Function
Main circuit terminals	
L1, L2, L3 (L1, L2)	3PH (or 1PH) AC input terminals, connected to the grid.
U, V, W	3PH (or 1PH) AC output terminals, connected to the motor usually.
(+)	(+) and (-) connect to the shared DC bus terminals.
(-)	PB and (+) connect to external braking resistor terminals.
PB	PE terminal. The PE terminals of each machine must be grounded reliably.
Control circuit terminals	
+10V	Locally provided +10V power supply. Max. output current: 50mA.
AI1	Input range: 0–10V/0–20mA Input resistance: 33kΩ for voltage input or 250Ω for current input Whether the input is current or voltage is selected through the toggle switch AI1 (I/V), and the function code P05.76 also needs to be set accordingly. Resolution: 1% accuracy across the full range
AI2	Input range: –10–10V/0–20mA Input resistance: 33kΩ for voltage input or 250Ω for current input Whether the input is current or voltage is selected through the toggle switch AI1 (I/V), and the function code P05.76 also needs to be set accordingly. Resolution: 1% accuracy across the full range
AO1	Output range: 0–10V/0–20mA Whether the output is current or voltage is selected through the toggle switch AO1 (I/V). Resolution: 1% accuracy across the full range
RO1A RO1B RO1C	Relay output. RO1A: NO; RO1B: NC; RO1C: common Contact capacity: 3A/AC 250V, 1A/DC 30V
GND	+10V power supply reference ground and analog signal reference ground.
HDO1	Switch capacity: 50mA/30V. Output frequency range: 0–50kHz It can be used as a standard DO terminal with push-pull output. You can set its function by setting P06.00.
485+	RS485 differential signal communication port. Use shielded twisted pairs for standard RS485 communication interfaces. You can determine whether to connect the 120Ω terminal matching resistor of RS485 communication through the toggle switch 485(ON/OFF).
485-	Type-C interface, which can be directly connected to a PC, using Modbus RTU as the communication protocol. When the VFD is not connected to the main power supply, it can be used to modify, save, import, and export parameters; when the VFD is connected to the main power supply, it can be used to control the VFD operation and monitor its running parameters.
USB	User power supply provided by the VFD. Max. output current: 100mA It can be used as an external NPN mode power input for the DI terminal (the switch must be turned to the NPN position).
+24V	+24V digital reference ground, which can be used as an external PNP mode input (the toggle switch must be set to the PNP position).
COM	DI1–DI4 functions: Effective input high level range: 10–30V Effective input low level range: 0–5V Max. input frequency: 1kHz Programmable digital input terminals, the functions of which can be set through the related parameters Whether the NPN or PNP mode is used can be selected through the toggle switch, and the external power wiring is supported. PTC function: DI4 can be configured with PTC overtemperature protection, which can be enabled through P05.04=57 and toggle switch setting. Overtemperature resistance: 3.6kΩ. Recovery resistance: 1.5kΩ. It supports the switchover between NPN and PNP. It can act as a high frequency pulse input channel, in addition to a digital input channel. Max. input frequency: 50kHz Duty ratio: 30%–70%
HD11	Safe torque off (STO) inputs STO redundant input, connected to the external NC contact. When the contact opens, STO acts and the VFD stops output. Safety input signal wires use shielded wires whose length is within 25m. The STO1 and STO2 terminals are short connected to +24V by default. Remove the jumper from the terminals before using the STO function.
STO1	
STO2	
Communication expansion card terminals	
+24E	An external 24V connection can be used for communication debugging.
COM	
EC IN	Five bus types are supported: PROFINET, EtherCAT, EtherNet IP, Modbus TCP, and EtherNet UDP EtherCAT can be only used in the IN port, while the other protocols do not distinguish the direction.
EC OUT	Five bus types are supported: PROFINET, EtherCAT, EtherNet IP, Modbus TCP, and EtherNet UDP EtherCAT can be only used in the OUT port, while the other protocols do not distinguish the direction.

4 Keypad



Digital display on LED keypad											
Display	Mean	Display	Mean	Display	Mean	Display	Mean	Display	Mean	Display	Mean
0	0	1	1	2	2	3	3	4	4	5	5
5	5	6	6	7	7	8	8	9	9	A	A
B	B	C	C	D	D	E	E	F	F	G	G
H	H	I	I	L	L	M	M	N	N	O	O
P	P	Q	Q	R	R	S	S	T	T	U	U
V	V	W	W	X	X	Y	Y	Z	Z	-	-

Indicator	Status	Meaning
RUN/TUNE	■ Steady on	The VFD is running.
	■ Blinking	The VFD is in parameter autotuning.
	■ Steady off	The VFD is stopped.
FWD/REV	■ Steady on	The VFD runs reversely.
	■ Steady off	The VFD runs forward.
LOCAL/REMOT	■ Steady on	The VFD uses communication as the command running channel.
	■ Blinking	The VFD uses terminal as the command running channel.
RUN/TUNE FWD/REV LOCAL/REMOT	■ All steady on, displaying the fault code	The VFD is in fault state.
	■ Blinking at the same time	The VFD is in pre-alarm state.
Unit indicator	■ A unit indicator that is on indicates the unit currently displayed on the keypad.	
	■ Hz	Hz
	■ RPM	Rotation speed unit
	■ A	Current unit
	■ %	Percentage
	■ V	Voltage unit

Key	Function
	Programming/Multifunction shortcut key Press it to enter or exit level-1 menus or delete a parameter. Press and hold it (at least 1s) to implement the function defined by the ones place of P07.02, which is jogging by default.
	Confirmation/Shifting key Press it to enter menus in cascading mode or confirm the setting of a parameter. Press it to select display parameters in the interface for the VFD in stopped or running state. Press and hold it (at least 1s) or to select digits to change during parameter setting.
	Up key Press it to increase data or move upward.
	Down key Press it to decrease data or move downward.
	Run key Press it to run or perform autotuning under keypad operation mode.
	Stop/Reset key P07.04 specifies the validity of the key function. Press it to stop running or autotuning in running state. Press it to reset in fault alarm state.


5 Quick running

5.1 Check before power-on

- Ensure that all terminals have been securely connected.
- Ensure that the motor power matches the VFD power.

5.2 Operating upon first power-on

After confirming the wiring and power are correct, close the air switch of the AC power at the VFD input side to power on the VFD.



6 Common function parameter setup

The following briefly describes only some common function parameters and typical values. "○" indicates that the value of the parameter can be modified when the VFD is in stopped or running state.

"◎" indicates that the value of the parameter cannot be modified when the VFD is in running state.

"●" indicates that the value of the parameter is detected and recorded, and cannot be modified.

(The VFD automatically checks and constrains the modification of parameters, which helps prevent incorrect modifications.)

Function code	Name	Description	Default	Modify
P02.23	Counter-emf of SM 1	0–10000	300	○
P03.00	Speed-loop proportional gain 1	0.0–200.0	20.0	○
P03.01	Speed-loop integral time 1	0.000–10.000s	0.200s	○
P03.03	Speed-loop proportional gain 2	0.0–200.0	20.0	○
P03.04	Speed-loop integral time 2	0.000–10.000s	0.200s	○
P03.11	Torque setting method selection of motor 1	0: P03.12 1: A11 2: A12 3: A13 4: High-speed pulse HD11 5: Multi-step speed running 6: Modbus/Modbus TCP communication 7: Ethernet communication 8: EtherCAT/PROFINET/EtherNet IP communication	0	○
P03.32	Enabling torque control of motor 1	0: Disable 1: Enable	0	○
P03.54	Current-loop band width of motor 1	0–2000	400	○
P04.01	Torque boost of motor 1	0.0–10.0%	0.0%	○
P04.09	V/F slip compensation gain of motor 1	0.0–200.0%	100.0%	○
P04.10	Low-frequency oscillation control factor of motor 1	0–100	10	○
P04.11	High-frequency oscillation control factor of motor 1	0–100	10	○
P05.00	HDI input type	0: HDI1 is high-speed pulse input 1: HDI1 is digital input	0	◎
P05.01	Function of DI1	0: No function 1: Run forward 2: Run reversely 3: Three-wire running control 4: Jog forward 5: Jog reversely 6: Coast to stop 7: Reset faults 8: Pause running 9: External fault input 10: Increase frequency setting (UP) 11: Decrease frequency setting (DOWN)	1	◎
P05.02	Function of DI2	0: No function 1: Run forward 2: Run reversely 3: Three-wire running control 4: Jog forward 5: Jog reversely 6: Coast to stop 7: Reset faults 8: Pause running 9: External fault input 10: Increase frequency setting (UP) 11: Decrease frequency setting (DOWN)	4	◎
P05.03	Function of DI3	0: No function 1: Run forward 2: Run reversely 3: Three-wire running control 4: Jog forward 5: Jog reversely 6: Coast to stop 7: Reset faults 8: Pause running 9: External fault input 10: Increase frequency setting (UP) 11: Decrease frequency setting (DOWN)	7	◎
P05.04	Function of DI4	0: No function 1: Run forward 2: Run reversely 3: Three-wire running control 4: Jog forward 5: Jog reversely 6: Coast to stop 7: Reset faults 8: Pause running 9: External fault input 10: Increase frequency setting (UP) 11: Decrease frequency setting (DOWN)	0	◎
P05.11	Function of HDI1	57: Motor overtemperature fault input (supported only by DI4)	0	◎
P05.42	AI1 lower limit	0.00V–P05.44	0.00V	○
P05.43	Corresponding setting of AI1 lower limit	–300.0%–300.0%	0.0%	○
P05.44	AI1 upper limit	P05.42–10.00V	10.00V	○
P05.45	Corresponding setting of AI1 upper limit	–300.0%–300.0%	100.0%	○
P05.47	AI2 lower limit	–10.00V–P05.49	–10.00V	○
P05.48	Corresponding setting of AI2 lower limit	–300.0%–300.0%	–100.0%	○
P05.49	AI2 middle value 1	P05.47–P05.51(V)	0.00V	○
P05.50	Corresponding setting of AI2 middle value 1	–300.0%–300.0%	0.0%	○
P05.51	AI2 middle value 2	P05.49–P05.53(V)	0.00V	○
P05.52	Corresponding setting of AI2 middle value 2	–300.0%–300.0%	0.0%	○
P05.56	AI3 lower limit	0.00V–P05.58	0.00V	○
P05.57	Corresponding setting of AI3 lower limit	–300.0%–300.0%	0.0%	○
P05.58	AI3 upper limit	P05.56–10.00V	10.00V	○
P05.59	Corresponding setting of AI3 upper limit	–300.0%–300.0%	100.0%	○
P05.66	HDI1 lower limit frequency	0.000kHz–P05.68	0.000kHz	○
P05.67	Corresponding setting of HDI1 lower limit frequency	–300.0%–300.0%	0.0%	○
P05.68	HDI1 upper limit frequency	P05.66–50.000kHz	50.000kHz	○
P05.69	Corresponding setting of HDI1 upper limit frequency	–300.0%–300.0%	100.0%	○
P05.76	AI input signal type selection	Bit0: AI1 input signal type selection 1: Current 2: Voltage Bit1: AI2 input signal type selection 1: Current 2: Voltage 3: High-speed pulse output 1: Digital output	0x0–0xF	◎
P06.00	HDO1 output type	0: Invalid 1: Running 2: Running forward 3: Running reversely 4: Jogging 5: VFD in fault 6: Frequency level detection FDT1 7: Frequency level detection FDT2 8: Frequency reached	0	○

Function code	Name	Description	Default	Modify
P06.04	HDO1 output	0: Invalid 1: Running 2: Running forward 3: Running reversely 4: Jogging 5: VFD in fault 6: Frequency level detection FDT1 7: Frequency level detection FDT2 8: Frequency reached	0	○
P06.05	RO1 output	0x00–0x1F Bit0–bit2: Reserved Bit3: HDO1 Bit4: RO1	0x00	○
P06.09	Output terminal polarity selection	0: Running frequency 1: Set frequency 2: Ramp reference frequency 3: Rotational speed 4: Output current 5: Output current 6: Output voltage 7: Output power	0	○
P06.26	AO1 output	–300.0%–P06.31	0.0%	○
P06.28	HDO1 high-speed pulse output	0.00–10.00V	0.00V	○
P06.29	AO1 output lower limit	0.00–10.00V	0.00V	○
P06.30	AO1 output corresponding to lower limit	P06.29–300.0%	100.0%	○
P06.31	AO1 output upper limit	0.00–10.00V	10.00V	○
P06.32	AO1 output corresponding to upper limit	0.000s–10.000s	0.000s	○
P06.41	HDO1 output lower limit	–300.0%–P06.43	0.0%	○
P06.42	HDO1 output corresponding to lower limit	P06.41–300.0%	100.0%	○
P06.43	HDO1 output upper limit	0.00–50.00kHz	0.00kHz	○
P06.44	HDO1 output corresponding to upper limit	0.00–50.00kHz	50.00kHz	○
P07.00	User password	0–65535	0	○
P07.27	Present fault type	–	–	●
P07.28	Last fault type	–	–	●
P07.29	2nd-last fault type	–	–	●
P07.30	3rd-last fault type	–	–	●
P07.31	4th-last fault type	–	–	●
P07.32	5th-last fault type	–	–	●
P08.28	Auto fault reset count	0–10	0	○
P08.29	Auto fault reset interval	0.1–3600.0s	1.0s	○
P08.41	Cooling-fan running mode	Setting range: 0x00–0x12 Ones place: Run mode 0: Normal mode 1: Permanent running after power-on 2: Run mode 2 Tens place: Speed regulation mode 0: Disable speed regulation 1: Speed regulation mode 1	0x10	○
P11.00	Protection against phase loss	Setting range: 0x000–0x011 Ones place: 0: Disable software input phase loss protection. 1: Enable software input phase loss protection. Tens place: 0: Disable output phase loss protection. 1: Enable output phase loss protection. Hundreds place: Reserved	0x011	○
P14.00	Local communication address	1–247 Note: The communication address of a slave cannot be 0.	1	○
P14.01	Communication baud rate	0: 1200 bps 1: 2400 bps 2: 4800 bps 3: 9600 bps 4: 19200 bps 5: 38400 bps 6: 57600 bps 7: 115200 bps	4	○
P14.02	Data bit check	0: No check (N, 8, 1) for RTU 1: Even check (E, 8, 1) for RTU 2: Odd check (O, 8, 1) for RTU 3: No check (N, 8, 2) for RTU 4: Even check (E, 8, 2) for RTU 5: Odd check (O, 8, 2) for RTU	1	○
P23.02	Received PZD2	0: Invalid	0	○
P23.03	Received PZD3	1: Set frequency	0	○
P23.04	Received PZD4	2: PID reference	0	○
P23.05	Received PZD5	3: PID feedback	0	○
P23.06	Received PZD6	4: Torque setting	0	○
P23.07	Received PZD7	5: FWD rotation upper-limit frequency setting	0	○
P23.08	Received PZD8	6: REV rotation upper-limit frequency setting	0	○
P23.09	Received PZD9	7: Electromotive torque upper limit	0	○
P23.10	Received PZD10	8: Braking torque upper limit	0	○
P23.11	Received PZD11	9: Virtual input terminal command 10: Virtual output terminal command	0	○

Function code	Name	Description	Default	Modify
P23.12	Received PZD12	11: V/F separation voltage setting 12: AO1 setting 1	0	○
P23.13	Sent PZD2	0: Invalid	0	○
P23.14	Sent PZD3	1: Running frequency	0	○
P23.15	Sent PZD4	2: Set frequency	0	○
P23.16	Sent PZD5	3: Bus voltage	0	○
P23.17	Sent PZD6	4: Output voltage	0	○
P23.18	Sent PZD7	5: Output current	0	○
P23.19	Sent PZD8	6: Actual output torque	0	○
P23.20	Sent PZD9	7: Actual output power	0	○
P23.21	Sent PZD10	8: Rotational speed	0	○
P23.22	Sent PZD11	9: Linear speed	0	○
P23.23	Sent PZD12	10: Ramp reference frequency	0	○
P23.24	Sent PZD12	11: Fault code	0	○
P23.25	Sent PZD12	27: VFD status word 2	0	○
P24.00	Expansion card protocol selection	0: PROFINET 1: EtherCAT 3: EtherNet IP 4: Modbus TCP 5: EtherNet UDP 6: PROFINET + EtherNet UDP 7: EtherCAT + EtherNet UDP 15: No communication expansion card	15	◎
P29.00	Expansion card type	0: No card 36: All-in-one expansion card—PROFINET communication card 41: All-in-one expansion card—EtherCAT communication card 43: All-in-one expansion card—EtherNet IP communication card 44: All-in-one expansion card—Modbus TCP communication card 45: All-in-one expansion card—Ethernet communication card 46: All-in-one expansion card—PROFINET + EtherNet communication card 47: All-in-one expansion card—EtherCAT + EtherNet communication card	0	●

7 Common faults and solutions

Fault code	Fault type	Possible cause	Solution
E4	Overcurrent during ACC	- ACC time too short. - Load too large or sudden change of load. - Start during motor rotating. 3PH output current imbalance. - When sensorless vector control is used for motor control, parameter autotuning is not performed. - When V/F control is used for motor control, V/F curve setting is abnormal. - There are strong external interference sources (contactor switchover or improper grounding). - Grid voltage too low. - Hardware fault.	- Increase the ACC time, or reduce the software current limit point through P11.06; if the process requires rapid ACC, increase the VFD capacity. - Increase the VFD capacity to ensure that the motor does not experience stalling, and that the load equipment functions without any exception. - Start after the motor stops, or select speed tracking start through P01.00. - Check the VFD output voltage and motor resistance to ensure three-phase balance. - Set the rated parameters according to the motor nameplate, and perform parameter autotuning through P00.15. - Adjust the frequency and voltage relationship set by the V/F curve, and reduce the voltage corresponding to the frequency. - To avoid strong interference, keep the motor cables away from contactors and ensure reliable grounding of the system. - Improve the power quality, or increase the VFD capacity. - Replace the VFD.
E5	Overcurrent during DEC	- DEC time too short. - Software current limit point setting too high. - Load too large or sudden change of load. 3PH output current imbalance. - When sensorless vector control is used for motor control, parameter autotuning is not performed. - When V/F control is used for motor control, V/F curve setting is abnormal. - There are strong external interference sources (contactor switchover or improper grounding). - Hardware fault.	- Increase the DEC time, or reduce the software current limit point through P11.06; if the process requires rapid DEC, increase the VFD capacity. - Reduce the software current limit point through P11.06. - Increase the VFD capacity to ensure that the motor does not experience stalling, and that the load equipment functions without any exception. - Check the VFD output voltage and motor resistance to ensure three-phase balance. - Set the rated parameters according to the motor nameplate, and perform parameter autotuning through P00.15. - Adjust the frequency and voltage relationship set by the V/F curve, and reduce the voltage corresponding to the frequency. - To avoid strong interference, keep the motor cables away from contactors and ensure

Fault code	Fault type	Possible cause	Solution
E6	Overcurrent during constant speed running	- Load too large or sudden change of load. - Software current limit point setting too high. 3PH output current imbalance. - When sensorless vector control is used for motor control, parameter autotuning is not performed. - When V/F control is used for motor control, V/F curve setting is abnormal. - There are strong external interference sources (contactor switchover or improper grounding). - Grid voltage too low. - Hardware fault.	- reliable grounding of the system. - Replace the VFD. - Increase the VFD capacity to ensure that the motor does not experience stalling, and that the load equipment functions without any exception. - Reduce the software current limit point through P11.06. - Check the VFD output voltage and motor resistance to ensure three-phase balance. - Set the rated parameters according to the motor nameplate, and perform parameter autotuning through P00.15. - Adjust the frequency and voltage relationship set by the V/F curve, and reduce the voltage corresponding to the frequency. - To avoid strong interference, keep the motor cables away from contactors and ensure reliable grounding of the system. - Improve the power quality, or increase the VFD capacity. - Replace the VFD.
E7	Overvoltage during ACC	- ACC time too short. - Grid voltage too high. - Start during motor rotating. - The load has a significant energy feedback. - Improper setting of overvoltage stall protection.	- Increase the ACC time or enable overvoltage stall protection. - Improve the power quality to comply with the VFD input voltage specifications (refer to product specifications). - Start after the motor stops, or select speed tracking start through P01.00. - Install a braking unit and energy feedback unit, or remove external factors that cause the load to generate power. - Enable overvoltage stall protection through P11.03, and lower the overvoltage stall protection voltage value of P11.04.
E8	Overvoltage during DEC	- Deceleration time too short. - Grid voltage too high. - The load has a significant energy feedback. - Improper setting of overvoltage stall protection.	- Increase the DEC time; if the process requires rapid DEC, braking units, energy feedback units can be added, or the magnetic flux braking function can be used. - Improve the power quality to comply with the VFD input voltage specifications (refer to product specifications). - Install a braking unit and energy feedback unit, or remove external factors that cause the load to generate power. - Enable overvoltage stall protection through P11.03, and lower the overvoltage stall protection voltage value of P11.04.
E9	Overvoltage during constant speed running	- Grid voltage too high. - The load has a significant energy feedback. - Improper setting of overvoltage stall protection.	- Improve the power quality to comply with the VFD input voltage specifications (refer to product specifications). - Install a braking unit and energy feedback unit, or remove external factors that cause the load to generate power. - Enable overvoltage stall protection through P11.03, and lower the overvoltage stall protection voltage value of P11.04.
E10	DC bus undervoltage	- Grid voltage too low. - Abnormal bus voltage display. - Abnormal precharge contactor closing. - Running under heavy load in the event of input phase loss.	- Increase grid input voltage. - Contact us. - Contact us. - Check for abnormal input power and loose input cables.
E11	Motor overload	- Grid voltage is too low. - Motor rated current is set incorrectly. - Motor stall or load jumps violently.	- Increase grid input voltage. - Reset the motor rated current in the motor parameter group. - Check the load and adjust torque boost.
E12	VFD overload	- ACC is too fast. - The motor is restarted during rotating. - Grid voltage is too low. - Load is too heavy. - VFD power is too small.	- Increase ACC time. - Avoid restart after stop. - Increase grid input voltage. - Load is too heavy. - VFD power is too small.
E13	Input side phase loss	- Phase loss or significant fluctuations in input L1, L2, or L3. - Input-side screws are loose.	- Check for abnormal input power and loose input cables. - Set P11.00 to screen out the fault.
E14	Output side phase loss	- Output cables are broken or short connected to the ground. - UVW phase loss (or the	- Check for loose or broken output cables. - Check for sharp load fluctuation and motor 3PH resistance

Fault code	Fault type	Possible cause	Solution
E16	Inverter module overheat	- Air duct is blocked or fan is damaged. - Ambient temperature is too high. - Long-time overload running.	- Ventilate the air duct or replace the fan. - Keep good ventilation to lower ambient temperature. - Select a VFD with larger power.
E17	External fault	DI terminal external fault input signal acted.	Check whether external device input is normal.
E18	Modbus/Modbus TCP communication fault	- Incorrect baud rate - Communication line fault. - Incorrect communication address. - Communication suffers from strong interference.	- Set a proper baud rate. - Check the communication port wiring. - Set the communication address correctly. - You are recommended to use shielded cables to improve anti-interference.
E19	Current detection fault	- Abnormal motor cable or motor insulation. - Motor capacity does not match with the VFD capacity. This fault may occur if the capacity difference exceeds five power classes. - Incorrect motor parameter setting. - The parameters gained from autotuning deviate sharply from the standard parameters. - Autotuning timeout. - Pulse current setting is too large.	- Remove motor cables to check. - Contact us. - Change the VFD model, or adopt V/F mode for control - Check motor wiring, motor type, and parameter settings. - Empty the motor load and re-perform autotuning. - Check whether the upper limit frequency is larger than 2/3 of the rated frequency. - Decrease the pulse current setting properly.
E20	Motor autotuning fault	- Motor capacity does not match with the VFD capacity. This fault may occur if the capacity difference exceeds five power classes. - Incorrect motor parameter setting. - The parameters gained from autotuning deviate sharply from the standard parameters. - Autotuning timeout. - Pulse current setting is too large.	- Remove motor cables to check. - Contact us. - Change the VFD model, or adopt V/F mode for control - Check motor wiring, motor type, and parameter settings. - Empty the motor load and re-perform autotuning. - Check whether the upper limit frequency is larger than 2/3 of the rated frequency. - Decrease the pulse current setting properly.
E21	EEPROM operation fault	- Error in reading or writing control parameters - EEPROM damaged.	- Press STOP/RST to reset. - Replace the control board.
E22	PID feedback offline.	- PID feedback offline. - PID feedback source disappears.	- Check PID feedback signal wires. - Check PID feedback source.
E23	Braking unit fault	- Braking circuit fault or braking pipe damage. - External braking resistor with small resistance.	- Check the braking unit, and replace with a braking pipe - Increase the braking resistance.
E24	Running time reached	Actual VFD running time longer than internally set running time.	Contact us.
E25	Electronic overload	The VFD reports overload pre-alarm according to the setting.	Check whether the overload pre-alarm point is set properly.
E27	Parameter upload error	- Keypad cable connected improperly or disconnected. - Keypad cable too long, causing strong interference. - Keypad or mainboard communication circuit error	- Check the keypad cable and re-plot to determine whether a fault occurs. - Check the surroundings to rule out interference source - Replace the hardware and seek maintenance services.
E28	Parameter download error	- Keypad cable connected improperly or disconnected. - Keypad cable too long, causing strong interference. - Keypad data storage error	- Check the surroundings to rule out interference source - Replace the hardware and seek maintenance services. - Check whether the version of the control board software of keypad backup parameter copy is the same as the version of the control board software of the VFD.
E30	Ethernet communication fault	No data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or disconnected.
E32	To-ground short-circuit fault	- The output of the VFD is short circuited to the ground. - Current detection circuit fault.	- Check whether the motor is short circuited to the ground and wiring is normal. - Check whether the motor wiring is normal. - Replace the main control board.
E34	Speed deviation fault	Load too heavy or stalled.	- Check for overload, increase speed deviation detection time, or prolong ACC/DEC time. - Check motor parameter settings and re-perform motor parameter autotuning. - Check speed loop control parameter settings.
E35	Mal-adjustment fault	- Load exception. - Incorrect SM parameter settings. - Autotuned motor parameters are inaccurate. - The VFD is not connected to the motor. - Flux weakening application.	- Check for overload or stalling. - Check motor parameter and correct EMF settings. - Re-perform motor parameter autotuning. - Increase the maladjustment detection time. - Adjust flux weakening coefficient and current loop parameters.

Fault code	Fault type	Possible cause	Solution
E36	Underload fault	The VFD reports underload pre-alarm according to the setting.	Check the load and overload pre-alarm threshold.
E40	Safe torque off	Safe torque off function is enabled by external forces.	-
E41	Safety circuit exception of STO channel 1	- The wiring of STO is improper. - Fault occurred to external switch of STO.	- Check whether terminal wiring of STO is proper and firm enough. - Check whether the external switch of STO can work properly.
E42	Safety circuit exception of STO channel 2	Channel safety circuit hardware fault.	- Replace the control board. - Note: Re-power on is required to clear the fault.
E43	Exception to both STO channel 1 and channel 2	Hardware fault occurred to STO circuit.	Replace the drive board.
E44	STO safety code FLASH CRC check fault	Drive board fault.	Replace the drive board.
E57	PROFINET communication timeout	No data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or disconnected.
E59	Motor overtemperature fault	- Equipment or ambient temperature too high. - AI/AO detected temperature inaccurate. - DI4 input motor overtemperature signal.	- Lower the equipment or ambient temperature. - Replace the temperature measuring resistor. - Check the external temperature measuring terminal signal.
E60	Communication card identifying failure	There is data transmission in communication card interface, but the card type cannot be identified.	- Check whether the expansion card in the slot is supported. - Stabilize the expansion card interface after power-off, and check whether the fault persists at next power-on. - Check whether the insertion port or card slot is damaged. If yes, replace the insertion port or card slot after power-off.
E63	Communication card communication timeout fault	No data transmission in the communication card interface.	Check whether the insertion port or card slot is damaged. If yes, replace the insertion port or card slot after power-off.
E66	EtherCAT communication timeout	No data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or disconnected.
E92	AI1 disconnection	- AI1 input too low. - AI1 wiring disconnected.	Connect a 5V or 10mA power source to check whether the input is normal.
E93	AI2 disconnection	- AI2 input too low. - AI2 wiring disconnected.	Check the wiring or replace the cable.
E94	AI3 disconnection	- AI3 input too low. - AI3 wiring disconnected.	Check the wiring or replace the cable.
E95	EtherNet IP communication timeout fault	No data transmission between the communication card and the host controller (or PLC).	Check whether the communication card wiring is loose or disconnected.
E96	No upgrade bootloader	Upgrade bootloader missing.	Contact us.
E587	Dual CPU communication fault 1	Dual CPU communication fault 1	Contact us.
E588	Dual CPU communication fault 2	Dual CPU communication fault 2	Contact us.

8 Product dimensions

Figure 8-1 Dimensions and hole positions for VFDs in frames A and B




Table 8-1 Dimensions and hole positions for VFDs in frames A and B

Product model	Frame	Outline dimensions (mm)			Mounting hole distance (mm)		Mounting hole diameter (mm)
		W1	H1	D1	W2	H2	
GD28-0R2G-S2	A	60	190	155	36	180	Ø5
GD28-0R4G-S2		60	190	155	36	180	Ø5
GD28-0R7G-S2		60	190	155	36	180	Ø5
GD28-0R2G-2		60	190	155	36	180	Ø5
GD28-0R4G-2		60	190	155	36	180	Ø5
GD28-0R7G-2		60	190	155	36	180	Ø5
GD28-0R4G-4	B	60	190	155	36	180	Ø5
GD28-0R7G-4		60	190	155	36	180	Ø5
GD28-1R1G-4		60	190	155	36	180	Ø5

Product model	Frame	Outline dimensions (mm)			Mounting hole distance (mm)		Mounting hole diameter (mm)
		W1	H1	D1	W2	H2	
GD28-1R1G-S2	B	70	190	155	36	180	Ø5
GD28-1R5G-S2		70	190	155	36	180	Ø5
GD28-2R2G-S2		70	190	155	36	180	Ø5
GD28-1R1G-2		70	190	155	36	180	Ø5
GD28-1R5G-2		70	190	155	36	180	Ø5
GD28-2R2G-2		70	190	155	36	180	Ø5
GD28-1R5G-4	C	70	190	155	36	180	Ø5
GD28-2R2G-4		70	190	155	36	180	Ø5
GD28-003G-4		70	190	155	36	180	Ø5
GD28-004G-4		70	190	155	36	180	Ø5

Figure 8-2 Dimensions and hole positions for VFDs in frame C




Table 8-2 Dimensions and hole positions for VFDs in frame C

Product model	Frame	Outline dimensions (mm)			Mounting hole distance (mm)		Mounting hole diameter (mm)
		W1	H1	D1	W2	H2	
GD28-004G-S2	C	90	235	155	70	72	Ø6
GD28-004G-2		90	235	155	70	72	Ø6
GD28-5R5G-2		90	235	155	70	72	Ø6
GD28-5R5G-4		90	235	155	70	72	Ø6

Figure 8-3 Dimensions and hole positions for VFDs in frame D




Table 8-3 Dimensions and hole positions for VFDs in frame D

Product model	Frame	Outline dimensions (mm)			Mounting hole distance (mm)		Mounting hole diameter (mm)
		W1	H1	D1	W2	H2	
GD28-7R5G-2	D	130	250	185	100	237	Ø6
GD28-011G-2		130	250	185	100	237	Ø6
GD28-011G-4		130	250	185	100	237	Ø6
GD28-015G-4		130	250	185	100	237	Ø6

Figure 8-4 Dimensions and hole positions for VFDs in frame E




Table 8-4 Dimensions and hole positions for VFDs in frame E

Product model	Frame	Outline dimensions (mm)			Mounting hole distance (mm)		Mounting hole diameter (mm)
		W1	H1	D1	W2	H2	
GD28-015G-2	E	160	300	190	130	287	Ø6
GD28-018G-4		160	300	190	130	287	Ø6
GD28-022G-4		160	300	190	130	287	Ø6

Appendix A Energy efficiency data

Table A-1 Power loss and IE class

Product model	(0:25)	(0:50)	(0:100)	(50:25)	(50:50)	(50:100)	(90:50)	(90:100)	Standby loss (W
---------------	--------	--------	---------	---------	---------	----------	---------	----------	-----------------