



## E5DC-QX2DSM-000

Temp. controller, PRO, DIN Rail 22,5mm, Uni. I/P, 1 x 12 VDC pulse OUT, 2 AUX, No cov., 24VAC/DC

# Specifications


|                          |                                                                    |
|--------------------------|--------------------------------------------------------------------|
| Size                     | 22.5 mm                                                            |
| Functions                | PID control                                                        |
| Number of control loops  | 1                                                                  |
| Temperature input type   | B, C (WRe5-26), E, J, JPt100, K, L, N, P (PLII), Pt100, R, S, T, U |
| Linear analog input type | 0 to 10 V, 0 to 20 mA, 0 to 5 V, 1 to 5 V, 4 to 20 mA              |
| Temperature range        | -200-2300 °C                                                       |
| Number of event inputs   | 0                                                                  |
| Number of alarm outputs  | 2                                                                  |
| Supply voltage AC        | 20.4-26.4 V                                                        |
| Supply voltage DC        | 20.4-26.4 V                                                        |
| Control output           | Voltage pulse                                                      |
| Terminal type            | Screw                                                              |

## Accessories



**E58-CIFQ2**

E5CB & E5CC and E5EC\* accessory, quick link programming cable, allows direct USB connection without requirement for communications card or power supply. Also the display will be powered (CX-Thermo v4.4 is needed). \*For E5EC front connection.



**EST2-2C-MV4**

CX-Thermo, direct 1 to 1 connecting software (1 to several if same TC type), for programming and monitoring E5\_N (version 5 & 6), E5ZN and CelciuX (EJ1)

## CAD Library



### Digital Temperature Controllers Brochure

EN PDF 4.45 MB



### E5CC Instruction Sheet

EN PDF 223 KB



### E5CC Getting Started Guide

EN PDF 5.23 MB



### E5CC/E5EC Getting Started Guide

EN PDF 2.55 MB



### E5CN-E5CC Conversion File Software

EN ZIP 613 KB



### E5EC Instruction Sheet

EN PDF 370 KB



### E5\_C Communications Manual

EN PDF 7 MB



### E5\_C - Digital Temperature Controllers Users Manual

EN PDF 14.4 MB



### E5\_C/E5\_C-T Digital Temperature Controller Datasheet

EN PDF 40.8 MB



### EAC Mark removal Discontinuation Notice

EN PDF 221 KB



### Panel Building Brochure

EN PDF 3.11 MB



### Thermac Temperature Simulation Software

EN ZIP 16.2 MB



### Thermac Temperature Simulation Tips and Tricks

#### Getting Started Guide

EN PDF 381 KB