

Up to PL e of EN ISO 13849-1 PNOZ s4



Safety relay for monitoring E-STOP pushbuttons, safety gates and light beam devices

Approvals

| | PNOZ s4 |
|--|---------|
| | ◆ |
| | ◆ |
| | ◆ |

Unit features

- ▶ Positive-guided relay outputs:
 - 3 safety contacts (N/O), instantaneous
 - 1 auxiliary contact (N/C), instantaneous
- ▶ 1 semiconductor output
- ▶ Connection options for:
 - E-STOP pushbutton
 - Safety gate limit switch
 - Reset button
 - Light barriers
 - PSEN
- ▶ A connector can be used to connect 1 PNOZsigma contact expander module
- ▶ Operating modes can be set via rotary switch
- ▶ LED indicator for:
 - Supply voltage
 - Input status, channel 1
 - Input status, channel 2
 - Switch status, safety contacts
 - Reset circuit
 - Error
- ▶ Plug-in connection terminals (either spring-loaded terminal or screw terminal)

Unit description

The safety relay meets the requirements of EN 60947-5-1, EN 60204-1 and VDE 0113-1 and may be used in applications with


- ▶ E-STOP pushbuttons
- ▶ Safety gates
- ▶ Light beam devices

Safety features

The relay meets the following safety requirements:

- ▶ The circuit is redundant with built-in self-monitoring.
- ▶ The safety function remains effective in the case of a component failure.
- ▶ The correct opening and closing of the safety function relays is tested automatically in each on-off cycle.
- ▶ The unit has an electronic fuse.

Block diagram



* only when $U_B = 48 - 240$ VAC/DC

Up to PL e of EN ISO 13849-1 PNOZ s4


Function description

- ▶ Single-channel operation: no redundancy in the input circuit, earth faults in the reset and input circuit are detected.
- ▶ Dual-channel operation without detection of shorts across contacts: redundant input circuit, detects
 - earth faults in the reset and input circuit,
 - short circuits in the input circuit and, with a monitored reset, in the reset circuit too.
- ▶ Dual-channel operation with detection of shorts across contacts: redundant input circuit, detects
 - earth faults in the reset and input circuit,

- circuit,
- short circuits in the input circuit and, with a monitored reset, in the reset circuit too,
- shorts between contacts in the input circuit.
- ▶ Automatic start: Unit is active once the input circuit has been closed.
- ▶ Manual reset: Unit is active once the input circuit is closed and then the reset circuit is closed.
- ▶ Monitored reset with falling edge: Unit is active once
 - the input circuit is closed and then the reset circuit is closed and opened again.
 - the reset circuit is closed and then opened again once the in-

- put circuit is closed.
- ▶ Monitored reset with rising edge: Unit is active once the input circuit is closed and once the reset circuit is closed after the waiting period has elapsed (see technical details).
- ▶ Reset with start-up test: The unit checks whether safety gates that are closed are opened and then closed again when supply voltage is applied.
- ▶ Increase in the number of available instantaneous safety contacts by connecting contact expander modules or external contactors/relays; A connector can be used to connect 1 PNOZsigma contact expander module.

Timing diagram



Key

- ▶ Power: Supply voltage
- ▶ Reset/start: Reset circuit S34 S34
- ▶ Input: Input circuits S11-S12, S21-S22
- ▶ Output safe: Safety contacts 13-14, 23-24, 33-34
- ▶ Output aux: Auxiliary contacts 41-42
- ▶ Out semi: Semiconductor output Y32
- ▶ ①: Automatic reset
- ▶ ②: Manual reset
- ▶ ③: Monitored reset with rising edge
- ▶ ④: Monitored reset with falling edge
- ▶ a: Input circuit closes before reset circuit

- ▶ b: Reset circuit closes before input circuit
- ▶ t₁: Switch-on delay
- ▶ t₂: Delay-on de-energisation
- ▶ t₃: Waiting period
- ▶ t₄: Waiting period reset circuit was closed

Wiring

Please note:

- ▶ Information given in the "Technical details" must be followed.
- ▶ Outputs 13-14, 23-24, 33-34 are safety contacts, output 41-42 is an auxiliary contact (e.g. for display).
- ▶ To prevent contact welding, a fuse should be connected before the output contacts (see technical details).
- ▶ Calculation of the max. cable runs I_{max} in the input circuit:

$$I_{\max} = \frac{R_{l\max}}{R_l / \text{km}}$$

R_{lmax} = max. overall cable resistance (see technical details)
R_l / km = cable resistance/km

- ▶ Use copper wire that can withstand 60/75 °C.
- ▶ Sufficient fuse protection must be provided on all output contacts with capacitive and inductive loads.

Up to PL e of EN ISO 13849-1 PNOZ s4

Preparing for operation

- ▶ Supply voltage

| Supply voltage | AC | DC |
|----------------|----|----|
| | | |

- ▶ Input circuit


| Input circuit | Single-channel | Dual-channel |
|---|----------------|--------------|
| E-STOP without detection of shorts across contacts | | |
| E-STOP with detection of shorts across contacts | | |
| Safety gate without detection of shorts across contacts | | |
| Safety gate with detection of shorts across contacts | | |
| Light beam device or safety switch with detection of shorts across contacts via ESPE (only when U_B = 24 VDC) | | |

Up to PL e of EN ISO 13849-1 PNOZ s4

► Reset circuit/feedback loop

| Reset circuit/feedback loop | Reset circuit | Feedback circuit |
|-----------------------------|---------------|------------------|
| Automatic reset | | |
| Manual/monitored reset | | |

► Semiconductor output




*Connect together the 0V connections on all the external power supplies

► Key

| | |
|-------|---------------------------|
| S1/S2 | E-STOP/safety gate switch |
| S3 | Reset button |
| | Switch operated |
| | Gate open |
| | Gate closed |

Up to PL e of EN ISO 13849-1 PNOZ s4

Terminal configuration



Installation

Install base unit without contact expander module:

- ▶ Ensure that the plug terminator is inserted at the side of the unit.

Connect base unit and PNOZsigma contact expander module:


- ▶ Remove the plug terminator at the side of the base unit and at the contact expander module.
- ▶ Connect the base unit and the contact expander module to the supplied connector before mounting the units to the DIN rail.

Installation in control cabinet

- ▶ The safety relay should be installed in a control cabinet with a protection type of at least IP54.
- ▶ Use the notch on the rear of the unit to attach it to a DIN rail (35 mm).
- ▶ When installed vertically: Secure the unit by using a fixing element (e.g. retaining bracket or end angle).
- ▶ Push the unit upwards or downwards before lifting it from the DIN rail.

Dimensions

*with spring-loaded terminals



Up to PL e of EN ISO 13849-1 PNOZ s4


Notice

This data sheet is only intended for use during configuration. For installation and operation, please refer to the operating instructions supplied with the unit.

Service life graph

The service life graphs indicate the number of cycles from which failures due to wear must be expected. The wear is mainly caused by the electrical load; the mechanical load is negligible.

U_B 24 VDC



Example

- Inductive load: 0.2 A
- Utilisation category: AC15
- Contact service life: 4,000,000 cycles


Provided the application requires fewer than 4,000,000 cycles, the PFH value (see technical details) can be used in the calculation.

To increase the service life, sufficient spark suppression must be provided on all output contacts. With capacitive loads, any power surges that occur must be noted. With contactors, use freewheel diodes for spark suppression.

We recommend you use semiconductor outputs to switch 24 VDC loads.

Up to PL e of EN ISO 13849-1 PNOZ s4

U_B 48-240 VAC/DC



Example

- Inductive load: 0.2 A
- Utilisation category: AC15
- Contact service life: 1 000 000 cycles

Provided the application requires fewer than 1 000 000 cycles, the PFH value (see technical details) can be used in the calculation.

To increase the service life, sufficient spark suppression must be provided on all output contacts. With capacitive loads, any power surges that occur must be noted. With contactors, use freewheel diodes for spark suppression.

We recommend you use semiconductor outputs to switch 24 VDC loads.

Technical details

Electrical data

| | |
|------------------------------------|---------------------------|
| Supply voltage | |
| Supply voltage U_B DC | 24 V |
| Supply voltage U_B AC/DC | 48 - 240 V |
| Voltage tolerance | -15 %/+10 % |
| Power consumption at U_B AC | 5.0 VA No. 750134, 751134 |
| Power consumption at U_B DC | 2.5 W |
| Frequency range AC | 50 - 60 Hz |
| Residual ripple DC | 20 %, 160 % |
| Voltage and current at | |
| Input circuit DC: 24.0 V | 50.0 mA |
| Reset circuit DC: 24.0 V | 50.0 mA |
| Feedback loop DC: 24.0 V | 50.0 mA |
| Number of output contacts | |
| Safety contacts (S) instantaneous: | 3 |
| Auxiliary contacts (N/C): | 1 |

Up to PL e of EN ISO 13849-1 PNOZ s4

Electrical data

Utilisation category in accordance with **EN 60947-4-1**

Safety contacts: AC1 at **240 V**

I_{min} : **0.01 A**, I_{max} : **6.0 A**

P_{max} : **1500 VA**

Safety contacts: DC1 at **24 V**

I_{min} : **0.01 A**, I_{max} : **6.0 A**

P_{max} : **150 W**

Auxiliary contacts: AC1 at **240 V**

I_{min} : **0.01 A**, I_{max} : **6.0 A**

P_{max} : **1500 VA**

Auxiliary contacts: DC1 at **24 V**

I_{min} : **0.01 A**, I_{max} : **6.0 A**

P_{max} : **150 W**

Utilisation category in accordance with **EN 60947-5-1**

Safety contacts: AC15 at **230 V**

I_{max} : **3.0 A** No. 750134, 751134

5.0 A No. 750104, 751104

Safety contacts: DC13 at **24 V** (6 cycles/min)

I_{max} : **4.0 A** No. 750134, 751134

5.0 A No. 750104, 751104

Auxiliary contacts: AC15 at **230 V**

I_{max} : **3.0 A** No. 750134, 751134

5.0 A No. 750104, 751104

Auxiliary contacts: DC13 at **24 V** (6 cycles/min)

I_{max} : **4.0 A** No. 750134, 751134

5.0 A No. 750104, 751104

Contact material

AgCuNi + 0.2 µm Au

External contact fuse protection ($I_K = 1 \text{ kA}$) to **EN 60947-5-1**

Blow-out fuse, quick

Safety contacts:

10 A No. 750104, 751104

6 A No. 750134, 751134

Auxiliary contacts:

10 A No. 750104, 751104

6 A No. 750134, 751134

Blow-out fuse, slow

Safety contacts:

4 A No. 750134, 751134

6 A No. 750104, 751104

Auxiliary contacts:

4 A No. 750134, 751134

6 A No. 750104, 751104

Circuit breaker 24 VAC/DC, characteristic B/C

Safety contacts:

4 A No. 750134, 751134

6 A No. 750104, 751104

Auxiliary contacts:

4 A No. 750134, 751134

6 A No. 750104, 751104

Semiconductor outputs (short circuit proof)

24.0 V DC, 20 mA

Max. overall cable resistance R_{lmax}

input circuits, reset circuits

30 Ohm

single-channel at U_B DC

30 Ohm No. 750134, 751134

single-channel at U_B AC

30 Ohm No. 750134, 751134

dual-channel without detect. of shorts across contacts at U_B DC

60 Ohm No. 750104, 751104

dual-channel without detect. of shorts across contacts at U_B AC

30 Ohm No. 750134, 751134

dual-channel with detect. of shorts across contacts at U_B DC

30 Ohm

dual-channel with detect. of shorts across contacts at U_B AC

30 Ohm No. 750134, 751134

Min. input resistance in the starting torque

110 Ohm

Safety-related characteristic data

PL in accordance with **EN ISO 13849-1: 2006**

PL e (Cat. 4)

Category in accordance with **EN 954-1**

Cat. 4

SIL CL in accordance with **EN IEC 62061**

SIL CL 3

PFH in accordance with **EN IEC 62061**

2.31E-09

SIL in accordance with **IEC 61511**

SIL 3

PFD in accordance with **IEC 61511**

2.03E-06

t_M in years

20

Up to PL e of EN ISO 13849-1 PNOZ s4

Times

| | |
|---|--------|
| Switch-on delay | |
| with automatic reset typ. | 170 ms |
| with automatic reset max. | 300 ms |
| with automatic reset after power on typ. | 350 ms |
| with automatic reset after power on max. | 600 ms |
| with manual reset typ. | 40 ms |
| on monitored reset with rising edge typ. | 35 ms |
| on monitored reset with rising edge max. | 50 ms |
| on monitored reset with falling edge typ. | 55 ms |
| on monitored reset with falling edge max. | 70 ms |

| | |
|--------------------------|-------|
| Delay-on de-energisation | |
| with E-STOP typ. | 10 ms |
| with E-STOP max. | 20 ms |
| with power failure typ. | 40 ms |
| with power failure max. | 80 ms |

| | |
|---|---|
| Recovery time at max. switching frequency 1/s | |
| after E-STOP | 100 ms No. 750104, 751104 50 ms No. 750134, 751134 |
| after power failure | 100 ms |

| | |
|---------------------------------------|--|
| Waiting period with a monitored reset | |
| with rising edge | 120 ms |
| with falling edge | 150 ms No. 750134, 751134 250 ms No. 750104, 751104 |

| | |
|--|--------|
| Min. start pulse duration with a monitored reset | |
| with rising edge | 30 ms |
| with falling edge | 100 ms |

| | |
|-------------------------------|---|
| Simultaneity, channel 1 and 2 | ∞ |
|-------------------------------|---|

| | |
|--|-------|
| Supply interruption before de-energisation | 20 ms |
|--|-------|

Environmental data

| | |
|---|--|
| EMC | EN 60947-5-1, EN 61000-6-2, EN 61000-6-4 |
| Vibration to EN 60068-2-6 | |
| Frequency | 10 - 55 Hz |
| Amplitude | 0.35 mm |
| Climatic suitability | EN 60068-2-78 |
| Airgap creepage in accordance with EN 60947-1 | |
| Pollution degree | 2 |
| Overvoltage category | III |
| Rated insulation voltage | 250 V |
| Rated impulse withstand voltage | 4.00 kV |
| Ambient temperature | -10 - 55 °C |
| Storage temperature | -40 - 85 °C |
| Protection type | |
| Mounting (e.g. cabinet) | IP54 |
| Housing | IP40 |
| Terminals | IP20 |

Mechanical data

| | |
|---|--|
| Housing material | |
| Housing | PC |
| Front | PC |
| Cross section of external conductors with screw terminals | |
| 1 core flexible | 0.25 - 2.50 mm ² , 24 - 12 AWG No. 750104, 750134 |
| 2 core, same cross section, flexible: | |
| with crimp connectors, without insulating sleeve | 0.25 - 1.00 mm ² , 24 - 16 AWG No. 750104, 750134 |
| without crimp connectors or with TWIN crimp connectors | 0.20 - 1.50 mm ² , 24 - 16 AWG No. 750104, 750134 |
| Torque setting with screw terminals | 0.50 Nm No. 750104, 750134 |
| Cross section of external conductors with spring-loaded terminals: Flexible with/without crimp connectors | 0.20 - 2.50 mm ² , 24 - 12 AWG No. 751104, 751134 |

Up to PL e of EN ISO 13849-1

PNOZ s4

Mechanical data

| | |
|---|---|
| Spring-loaded terminals: Terminal points per connection | 2 No. 751104, 751134 |
| Stripping length | 9 mm No. 751104, 751134 |
| Dimensions | |
| Height | 102.0 mm No. 751104, 751134 96.0 mm No. 750104, 750134 |
| Width | 22.5 mm |
| Depth | 120.0 mm |
| Weight | 190 g No. 750104, 751104 210 g No. 750134, 751134 |

No. stands for order number.

It is essential to consider the relay's service life graphs. The relay outputs' safety-related characteristic data is only valid if the values in the service life graphs are met.

The PFH value depends on the switching frequency and the load on the relay output.

If the service life graphs are not accessible, the stated PFH value can be

used irrespective of the switching frequency and the load, as the PFH value already considers the relay's B10d value as well as the failure rates of the other components.

All the units used within a safety function must be considered when calculating the safety characteristic data.

The standards current on **2006-04** apply.

Conventional thermal current

| Number of contacts | I_{th} (A) at U_B DC | I_{th} (A) at U_B AC |
|--------------------|--|----------------------------------|
| 1 | 6.00 A | 6.00 A No. 750134, 751134 |
| 2 | 6.00 A | 6.00 A No. 750134, 751134 |
| 3 | 4.50 A No. 750134, 751134 5.00 A No. 750104, 751104 | 4.50 A No. 750134, 751134 |

Order reference

| Type | Features | Terminals | Order no. |
|-----------|-----------------|------------------------------|-----------|
| PNOZ s4 | 24 VDC | With screw terminals | 750 104 |
| PNOZ s4 C | 24 VDC | With spring-loaded terminals | 751 104 |
| PNOZ s4 | 48 – 240 VAC/DC | With screw terminals | 750 134 |
| PNOZ s4 C | 48 – 240 VAC/DC | With spring-loaded terminals | 751 134 |