Autonics MULTI FUNCTION TIMER AT11DN/AT11EN SERIES

INSTRUCTION MANUAL

Thank you for choosing our Autonics product. Please read the following safety considerations before use.

Safety Considerations

**Please observe all safety considerations for safe and proper product operation to avoid hazards.

 $st \Lambda$ symbol represents caution due to special circumstances in which hazards may occur.

↑ Warning Failure to follow these instructions may result in serious injury or death

↑ Caution Failure to follow these instructions may result in personal injury or product damage.

- 1. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) Failure to follow this instruction may result in personal injury, economic loss or fire.

 2. Do not use the unit in the place where flammable/explosive/corrosive gas, humidity, direct sunlight.
- radiant heat, vibration, impact, or salinity may be present. Failure to follow this instruction may result in explosion or fire
- 3. Install on a device panel to use.
- Failure to follow this instruction may result in fire or electric shock.
- 4. Do not connect, repair, or inspect the unit while connected to a power source. Failure to follow this instruction may result in fire or electric shock.
- 5. Check 'Connections' before wiring.
- Failure to follow this instruction may result in fire
- 6. Do not disassemble or modify the unit.
- Failure to follow this instruction may result in fire or electric shock

△ Caution

- Use the unit within the rated specifications
- Failure to follow this instruction may result in fire or product damage
- 2. Use dry cloth to clean the unit, and do not use water or organic solvent.
- Failure to follow this instruction may result in fire or electric shock.

 3. Keep metal chip, dust, and wire residue from flowing into the unit.
 Failure to follow this instruction may result in fire or product damage.

Ordering Information



Unit Description

Operation/Power indicator (Flashes for timer operation, Turns ON for timer stop)

Time range indication Time range setting switch:

Output operation mode indicator (sec min hour 10h mode)




Output operation


mode setting SW

Time Specifications

	Time range	Time unit	Time setting range
	0.5	sec	0.05 to 0.5 sec.
	1.0		0.1 to 1 sec.
	5		0.5 to 5 sec.
	10		1 to 10 sec.
	0.5	min	0.05 to 0.5 min.
	1.0		0.1 to 1 min.
	5		0.5 to 5 min.
	10		1 to 10 min.
	0.5	hour	0.05 to 0.5 hour
ut	1.0		0.1 to 1 hour
	5		0.5 to 5 hour
	10		1 to 10 hour
on	0.5	10h	0.5 to 5 hour
	1.0		1 to 10 hour
	5		5 to 50 hour
:)	10		10 to 100 hour
on			

Connections






X1: AC/DC voltage: 100-240VAC 50/60Hz, 24-240VDC : 24VAC 50/60Hz, 24VDC DC voltage: 12VDC

- *The above specifications are subject to change and some models may be discontinued without notice.
- XBe sure to follow cautions written in the instruction manual and the technical descriptions (catalog, homepage)


Dimensions








Panel cut-out Min. 65




Output Operation Mode

[t: Setting time, t=t1+t2, t>t-a]



※AT11EN-□ model only supports Instantaneous contact. If power is cut or the RESET terminal is short-circuited, the timer will be RESET.

XIf the INHIBIT terminal is short-circuited during a time limit operation, the time will stop In case of F, F1 output operation mode, setting time should be over 100ms. If not, it may cause abnormal output operation due to under 100ms of setting time



(unit: mm)

Bracket X1: Refer to time specifications for control time setting range by model.

(€ :**FU**:s

- X2: The weight includes packaging. The weight in parenthesis is for unit only
- *Environment resistance is rated at no freezing or condensation

Cautions during Use

Specifications

Control time setting range

Allowable voltage range

Power consumption

Return time

Input

Control

output

Relav

Time operation

Min. input signal width

life cycle Electrical

Temperature error

Dielectric strenath

Insulation resistance

Environ- Ambient temp.

Ambient humid

Repeat error

Setting error

Voltage error

Approval

Accessory

Weight**2

Contact type

AT11DN-

• 12VDC==

Max. 100ms

Signal ON Start

Multi Function Timer

90 to 110% of the rated voltage

•Max. 3.5VA (100-240VAC~)

START, RESET, INHIBIT: approx. 50ms

Min. 100,000 operations (250VAC 5A resistive load)

Max. 1.5W (24-240VDC:...)

•Max. 4VA (24VAC~),

Max. 1.5W (24VDC=)

•Max. 1W (12VDC ...)

Time limit DPDT (2c)

Max. ±0.2% ±10ms

Max. ±5% ±50ms

Max. ±0.5%

Max +2%

Min. 10.000.000 operations

100MΩ (at 500VDC megger)

2 000VAC 50/60Hz for 1 minute

-10 to 55°C, storage: -25 to 65°C

Approx. 132.2g (approx. 85g)

35 to 85%RH, storage: 35 to 85%RH

0.05 sec. to 100 hour

AT11EN-

Max. 4.3VA (100-240VAC ~),

nstantaneous SPDT (1c)+Time limit SPDT (1c)

Approx. 134.7g (approx. 87.5g)

Max. 2W (24-240VDC==)

Max. 4.5VA (24VAC~),

Max. 2W (24VDC==)

•Max. 1.5W (12VDC=)

•100-240VAC~ 50/60Hz, 24-240VDC= universal •24VAC~ 50/60Hz, 24VDC= universal

START, RESET, INHIBIT: [No-voltage input] - Short-circuit impedance: max. 1kΩ,


Residual voltage: max. 0.5VDC, Open-circuit impedance: max. 100kΩ

Contact capacity | 250VAC~ 5A, 24VDC= 5A resistive load | 250VAC~ 5A, 30VDC= 5A resistive load


Model

Function

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
 12VDC, 24VDC, 24VAC power supply should be insulated and limited voltage/current or Class 2. SELV power. supply device.
- 3. When supplying or turning off the power, use a switch or etc. to avoid chattering.
 4. Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
 5. In order to block peripheral current, use isolation transformer which of secondary part is not grounded as (Figure 1) to supply power to the external input device.



6. In order to avoid leakage current flowing, connect resistance and condenser as (Figure 3). If connect as (Figure 2), it may cause malfunction due to leakage current.



- 7. Do not connect two or more timers with only one input contact or transistor simultaneously
- 8. Keep away from high voltage lines or power lines to prevent inductive noise. In case installing power line and input signal line closely, use line filter or varistor at power line and shielded wire at input signal line.
- Do not use near the equipment which generates strong magnetic force or high frequency noise
- 9. Change setting time, time range, operation mode or etc. after turning off the power of the timer.
- 10. This unit may be used in the following environments.
 - (1) Indoors (in the environment condition rated in 'Specifications') ②Altitude max. 2,000m
- ③Pollution degree 2
- (a) Installation category II

18, Bansong-ro 513Beon-gil, Haeundae-gu, Busan, Republic of Korea, 48002 www.autonics.com | +82-51-519-3232 | sales@autonics.com